

#23

TAIL SHAFT ASSY	977-000156
HEAD SHAFT BEARINGS	900-1905-07 (2 7/16 P.K.B)
TAIL SHAFT BEARINGS	900-1904-72 (2 7/16 P.B.)
IDLER WHEEL ASSY	977-000156
IDLER WHEEL BEARINGS	900-1905-10 (2" P.B)
DRIVE MOTOR	900-3901-39 (RE24080410)
GEAR BOX	900-3901-54 (16-FF-1-4-5)
DRIVER SPROCKET	900-1905-21 (100Q12)
DRIVER SPROCKET BUSHING	900-1903-43 (Q1 X 2 1/4)
DRIVEN SPROCKET	900-1905-24 (100R26)
DRIVEN SPROCKET BUSHING	900-1900-08 (R1 X 2- 7/16)
100H CHAIN 22 LINKS LONG	977-000058
CHAIN GUARD	977-000057
CONTACT BLOCK	900-2901-05 (Hyd Shutdown)
PUSH/PULL BUTTON	900-2901-03 (Hyd Shutdown)
HYD SHUTDOWN BOX	900-2901-06 (Hyd Shutdown)

DISCHARGE:

BOTTOM SECTION ASSY	977-000038
BOTTOM FAN IDLER WHEEL	977-000063
IDLER WHEEL BEARINGS	900-1905-10 (2" P.B)
2 ND SECT. FOLD CYL.	900-3910-11 (3024)
3 RD SECT. FOLD CYL.	900-3910-11 (3024)
TROUGHING ROLLS	900-1905-98
SINGLE TROUGHING ROLL	900-9902-04
RETURN ROLLER	900-1905-31 (48" LONG)
GUIDE ROLLER	900-1905-33
MIDDLE SECTION ASSY	977-000039
HYD MANIFOLD BLOCK	976-010878
TOP SECTION ASSY	977-000040
SHAKER ROLLER	977-000062
SHAKER ROLLER BEARING	900-1901-08 (1" FLANGE)
STAINLESS STEEL CHUTE	976-000425
HYD DRIVE MOTOR	900-3901-39 (RE24080400)
TORQUE ARM	980-0124-98
MAGNETIC HEAD ASSY	977-000101
NON-MAGNETIC HEAD ASSY	977-000102
MAG. HEAD ASSY BEARINGS	900-1905-10 (2" P.B.)
LEE- TITE COUPLER	976-000408