

**MODEL 3680**

# **CONTROLS**

**MODEL 3680 BASIC LOCATION OF RADIO REMOTE CONTROLS**  
(FOR AUTO FEED CONTROL WITH A BLACKFACE)

- |                                  |   |
|----------------------------------|---|
| 1. Power On & Off Switch         | 5. Feedwheel Forward & Reverse Switch       |
| 2. Yoke Up & Feed Reverse Switch | 6. Concave Door Open & Close Switch         |
| 3. Throttle Up & Down Switch     | 7. Infeed Conveyor Forward & Reverse Switch |
| 4. Engine Stop & Reset Switch    | 8. Monitor Light                            |

