

# REPLACEMENT PARTS SECTION

Depending on what replacement parts you are ordering the following information will be needed:

RECYCLER COMPONENTS

Serial Number  
Model Number of Recycler

ENGINE COMPONENTS

Engine Size  
Engine Serial Number  
Engine Spec. Number

CLUTCH COMPONENTS

Name of Manufacturer  
Serial Number  
"Assembly Number of Clutch

## NOTE

When ordering any replacement parts you should have the serial number (S/N) of the machine to ensure that you receive the correct replacement part. See page 6 for typical serial number & work order number locations.

## NOTE

All nuts, bolts, washers, and all other components can be ordered by physical description.

## NOTE

Some of the components shown in this section are for optional equipment and may not apply to every machine.

Smoracy, LLC reserves the right to make changes in models, size, design, installations and applications on any part without notification.

Smoracy, LLC