

LOWER & MID DISCHARGE CONVEYOR

LOCATION	Part Number	Discription
1	900-1905-10	Bottom Idler Wheel Bearing
2	976-001634	Bottom Idler Wheel Bearing Baker Plate
3	976-020416	Bottom Idler Wheel Bearing Clamp Plate
4	977-000284	Bottom Idler Wheel Bearing Adjusting Bolt
5	976-011643	Bottom Idler Wheel Bearing Adjusting Rail
6	976-001646	Bottom Idler Wheel Bearing Adjusting Clamp Plate
7	976-021017	Bottom Idler Wheel Bearing Adjusting Block
8	977-000247	Fanned Bottom Idler Wheel Assembly
9	977-000185	Solid Bottom Idler Wheel Assembly
10	900-1906-14	Slide Guide Roller
11	900-1907-41	Return Roller Mount
12	900-1906-13	Frame Mounted Return Roller
13	977-000038	Lower Section Assembly
14	900-3910-11	Lower to Mid Section Hydraulic Cylinder
15	977-000180	1" Pivot Pin
16	977-000179	1 -1/2" Pivot Pin
17	900-1905-98	Troughing Roll Assembly
18	900-3910-11	Mid to Upper Section Hydraulic Cylinder
19	977-000039	Mid Section Assembly

